



USER MANUAL – EN

IN 26626 Exercise bike inSPORTline Velocer UB



CONTENTS

SAFETY INSTRUCTIONS..... 3
DRAWING 4
PART LIST..... 5
ASSEMBLY 8
CONSOLE 15
USE 29
EXERCISING INSTRUCTIONS 30
CORRECT BODY POSTURE 31
MAINTENANCE 31
STORAGE 31
IMPORTANT NOTICE..... 31
ENVIRONMENT PROTECTION 31
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 32


SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

SAFETY INSTRUCTIONS

- Please read the manual carefully before first use and keep it for future reference.
- To ensure maximum safety, carry out regular checks for damage or wear of parts.
- If another person will also be using the device, it is important that they are familiar with all the instructions given in this manual.
- Only 1 person can exercise on the device.
- Before using the device, check that all screws and nuts are properly tightened and that all joints are in good condition.
- Before starting the exercise, remove all dangerous objects with sharp edges from around the device.
- Only use the device if it is in good condition and fully functional.
- A damaged, worn or defective part must be replaced with a new one as soon as possible. Stop using the device until it is fully functional again.
- Before allowing a child to exercise on the machine, consider their mental and physical condition. Children can only exercise under the supervision of an adult who will supervise the correct use of the device. The exercise bike is not a toy for children.
- It is necessary to ensure sufficient free space around the entire device, min. 0.6 m.
- Be aware that improperly conducted or excessive exercise can lead to health damage.
- Before using the product, it must be secured against unwanted movement using the adjustable feet.
- No adjustable part may protrude and limit the user's movement. Avoid contact with joints during exercise.
- Place the device on a flat surface and ensure its stability.
- Wear appropriate clothing and shoes for exercise. Do not exercise in clothing that could get caught in the device (e.g. clothing that is too long and loose). We recommend sturdy sports shoes with non-slip soles.
- Consult your doctor before starting any exercise program. Your doctor can suggest a suitable exercise program and recommend a suitable diet.
- Assemble the product according to the instructions in the manual and use only the original supplied parts. Before starting assembly, check that all the parts listed in the parts list have been supplied.
- Place the device on a dry and flat surface and protect it from moisture. Alternatively, place a non-slip mat under the device. This will prevent damage to the surface under the device.
- It should be noted that the exercise machines and their accessories are not intended for playing. Therefore, the device may only be used by persons who are familiar with its correct operation.
- Stop exercising immediately if you experience dizziness, nausea, chest pain, or any other discomfort. Consult your doctor about further exercise.
- All adjustable parts must be set with regard to their extreme positions.
- Do not exercise immediately after eating.
- **Maximum load capacity:** 150 kg
- **Category:** SA for commercial use

- **WARNING!** The heart rate monitoring system may not be accurate. Overexertion during training can cause serious injury or death. If you feel nauseous, stop exercising immediately!

DRAWING



PART LIST











No.	Name	Qty.
A	Main frame	1
1	Main frame paint	1
2	Seat tube slider	1
3	Power switch group	1
4	Power outlet	1
5	Overcurrent protection	1
6	Power switch	1
7	Connecting line	1
8	Two-way bearing	2
9	Lower control board	1
13	Plate	1
14	Washer S20	2
15	Philips screw	2
16	Philips screw	3
81	Crank axle	1
B	Magnetic flywheel	1
17	Magnetic control	1
18	Flywheel positioning plate	2
19	Spring washer M10	1
20	Nut M10x5T	3
C	Idle wheel	1
21	Flywheel set	1
22	Tension spring	1
23	Washer S10	3
24	Flat washer OD10*ID19*1.5T	1
25	Bearings	2
26	Flat washer 5*16*1T	1
27	Phillips screw M5x10L	1
D	Left crank set	1
15	Phillips screw	3
29	Crank cover	1
30	Allen bolt M8*30L	1
31	Allen bolt M6*12L	1
32	Flat washer d6*D22*2T	1
33	Flat washer d4.3*D12*1T	3
E	Right crank set	1


15	Phillips screw	3
30	Allen bolt M8*30L	1
31	Allen bolt M8*30L	1
32	Flat washer d6*D22*2T	1
33	Flat washer d4.3*D12*1T	3
34	Crank cover	1
F	Pulley set	1
35	Belt	1
36	Magnet	1
37	Allen bolt M8*20L	4
38	Nut M8	4
G	Seat post	1
16	Phillips screw ST4*12L	2
39	Seat post engraving	1
40	Seat post cover	1
H	Saddle slider	1
41	Saddle set	1
42	Seat	1
43	Saddle slider	2
44	Nut	1
45	Screw M10*70L	1
46	Phillips screw 4*12	4
54	Bearings	1
I	Front stabilizer	1
47	Front stabilizer cover	1
48	Transport wheels	2
49	Cover	2
50	Rubber foot	2
51	Allen bolt M8*40L	2
52	Allen bolt M8*90L	4
J	Rear stabilizer	1
16	Phillips screw	2
53	Rear stabilizer cover	1
49	Cover	2
50	Rubber foot	2
51	Allen bolt M8*90L	4
K	Handle post	1
55	Handle cover	1

56	Left cover	1
57	Right cover	1
58	Allen bolt M8*65L	2
59	Allen bolt M8*60L	4
60	Screw M4*10L	4
L	Handles	1
61	Handle assembly	1
62	Bottle holder and screws	1
63	Heart rate sensor covers	2
64	Heart rate sensors	2
65	Covers	2
66	Screw 3*14	4
M	Covers and others	1
9	Spring clip	1
15	Phillips screw	4
16	Phillips screw ST4*12L	5
67	Left cover	1
68	Left logo	2
69	Left seat cover	1
70	Right cover	1
71	Sticker	2
72	Right seat cover	1
73	Screw	9
4	YJ-9900 engine	1
5	Motor cable	1
10	Belt	1
11	Heart rate sensors	2
12	Mounting kit	1
27	Screw M5*10L	3
74	Console	1
75	Saddle engraving	1
76	Allen bolt M6*16L	2
77	Handle cover	2
78	Left pedal	1
79	Right pedal	1
80	Hand knob	1
82	Power cable	1
83	Console cable 1465 mm	1


84	Console cable 800 mm	1
85	Socket	1
86	Transformer	1
88	220 mm - 6 pin (blue)	1
89	220 - 6 pin (red)	1
90	925 mm, 6pin (blue), 1 terminal 4pin 2.54 male, 1 terminal divided into 2 terminals 110 female, sensor head connection (black)	1
91	925 mm, 6pin (blue), 1 terminal 4pin 2.54 male, 1 terminal divided into 2 terminals 110 female, sensor head connection (black)	1

ASSEMBLY

			
Allen key 4mm	Allen key 5 mm	Screwdriver	
Step 1	Step 2	Step 2	
			
51. Bolt M8*40L, 4x	58. Bolt M8*65L, 4x	52. Bolt M8*90L, 4x	
Step 3	Step 4	Step 5	Step 7
			
27. Bolt M5*10L, 3x	59. Bolt M8*55L, 4x	50. Bolt M4*10L, 4x	76. Bolt M6*16L, 2x




- | |
|-----------------------|
| 1. Heart rate sensors |
| 2. Bottle holder |
| 3. Saddle |
| 4. Saddle lock |
| 5. Seat post |
| 6. Rear stabilizer |
| 7. Power cable |
| 8. Pedals |
| 9. Front stabilizer |
| 10. Hand knob |
| 11. Handle post |
| 12. Handle post cover |
| 13. Console |




Step 1

Attach the rear stabilizer (J) to the main frame with bolts (51).




Step 2

Connect the cables before attaching the handle post (K) to the main frame. Make sure the handle post (K) is inserted into the main frame before attaching the front stabilizer (I) with the bolts (52).




Step 3

Before attaching the console (74) to the handle post, connect the cables of the same color. Be careful not to pinch the cables between the frames.




Step 4

Connect cables of the same color and fix the handles (L) to the handle post with bolts (59).




Step 5

Attach the covers (56 and 57) to the handle post with bolts (60).




Step 6

Turn and pull out the hand knob and at the same time pull out the seat post using the eyelet.




Step 7

Attach the seat slider (75) to the seat post with bolts (76). Attach saddle (42) to saddle slider (75) and secure with nuts (D).



Step 8

Attach the pedals (78).



SEAT ADJUSTMENT


Adjust the saddle to make the exercise as comfortable as possible.



TRANSPORT


Step 1

Grasp the handles on both sides, push and move the machine onto the transport wheels on the front stabilizer.



Step 2

Carefully move the machine on the transport wheels. Do not slide the machine stabilizers across the floor.



WARNING

Do not lift the machine by the seat and console.




WARNING


Do not move the machine by holding the console.



INCORRECTLY



INCORRECTLY



QUICK CONTROL

Left side - START/STOP

After selecting a program, you can start or pause the program using the START/STOP button. You can turn off the suspended program or continue the exercise.

Right side - Resistance

Use the buttons on the right to adjust the pedaling resistance.

CONSOLE

Wireless charger

The wireless charger with dimensions of 24*9.4 cm allows you to charge smart devices with a display up to 7.2 inches.


Make sure your smart device is positioned correctly. When charging is active, the symbol is displayed ((⚡)).



Note: if you are using covers, stickers or rings that contain metal, they must be removed before using the charger.



1. Buttons	5. Control buttons
2. TFT LCD display	6. 3D speakers
3. Saves energy	7. USB-A port
4. Wireless charger	8. USB-C port



1. Stops or pauses the program	2. Starts the program
3. Press the button to start the console, hold the button for 3 seconds to turn off the console	4. Increase / decrease resistance
5. Wireless charging	6. Increase / decrease volume
7. HIIT program	8. User data adjustment

POWER ON

Launching the console will display the logo and then go into standby mode.


QUICK START: Enter program selection and select quick start.

PROGRAMS: You must create an account or select an already created account


SLEEP MODE: After 300 seconds of inactivity, the console switches to sleep mode.



SETTINGS



- A. Unit: Metric / Imperial
- B. Resistance setting
 - Auto mode: achieve precise performance by varying load and pedaling speed
 - Manual mode: achieving different performance using precisely given load and pedaling speed
- C. Power display: In manual mode, you can select WATT or MET units
- D. Button sounds
- F. Update if USB with update is plugged in



- E. SLEEP MODE: enable or disable sleep mode
- F. Update if USB with update is plugged in



LANGUAGE

There are several languages to choose from.








BT SPEAKER



IOS MUSIC CONNECT


Step 1

Select  to turn on. The icon  will flash during pairing. The icon will disappear if pairing is not completed within 30 seconds.





Step 2

Turn on Bluetooth on your device and select BT-Speaker.




Step 3

If the icon  is displayed, the speaker is connected and you can control the volume.





Step 4

Select music.





ANDRIOD

Step 1


Select  to turn on. The icon  will flash during pairing. The icon will disappear if pairing is not completed within 30 seconds.

Krok 2

Turn on Bluetooth on your device and select BT-Speaker.






Step 3

If the icon  is displayed, the speaker is connected and you can control the volume.


Krok 4


Select music.





Note: To disconnect the device, press . If you want to connect another device, you need to disconnect the previous device.


ICON DESCRIPTION



APP  Connecting the console using applications with the FTMS protocol.

 Connection with Bluetooth chest belt.

 Connection with a wireless charger.

 Connecting the phone and speakers



QUICK START



PULSE: If you wear the chest belt or hold the pulse sensors on the handles, the pulse rate will be displayed

BLUETOOTH: If the chest belt is connected to a third-party app, an icon will appear

CALORIES: Number of calories burned during exercise

TIME: Training time

RPM/SPEED: Revolutions per minute or speed

DISTANCE: Distance during exercise

KJ: Energy by momentary movement

WATT: Exercise power

INTENSITY: Exercise resistance

WIRELESS CHARGER: Icon will be displayed during wireless charging

VOLUME: Speaker volume



ACCOUNT CREATION


Create a user. You must enter your name, height, weight and gender.

Name (name) – max. 10 characters



Age (age) – range: 10 – 90, default value: 35


Height (height) – range: 100 – 250, default value: 160

Weight – range: 20 – 200, default value 70




Press + to select one of 54 avatars. If you don't choose one, it will be randomly assigned to you.



After setting all data, press the key .

After creating a profile, you can select a user profile.





By pressing the pencil you can profile:

EDIT – edit data values

REMOVE – delete profile



There are 25 different programs to choose from.





MANUAL



TIME COUNTDOWN



DISTANCE COUNTDOWN



CALORIES COUNTDOWN



WARM UP



INTENSITY INTERVAL



VALLEY



SLOPE



MOUNTAIN



CONSTANT



HILLS



FAT BURNING



CARDIO



STRENGTH



HRC



CLIMB



RECOVERY



USER PROGRAM X3



CONSTANT SPEED



CONSTANT WATT

QUICK START

The program will add all values. When the program starts, a 3-second countdown is displayed. After completing the exercise, all measured values are displayed (WORKOUT SUMMARY)



WORKOUT SUMMARY	
DURATION	01:03
DISTANCE	10.5 KM
CALORIES	123 KCAL
AVG. PULSE	120 BPM
MAX. PULSE	131 BPM
AVG. SPEED	10.0 KM/H
AVG. WATT	87 WATT
TOTAL. KJ	68 KJ

Buttons: SKIP, SAVE



MANUAL

Quick start exercise program.

COUNTDOWN PROGRAMS



Time
countdown



Distance countdown



Calories countdown

You can only set one countdown program at the same time.

Step 1: Select GOAL

Step 2: Set the desired value using the numeric keypad.

Step 3: Confirm with the button .



SET YOUR WORKOUT VALUE

WORKOUT DURATION: 30 MIN

1	2	3	←
4	5	6	←
7	8	9	✓
↶	0	↷	✓



SET YOUR WORKOUT VALUE

TARGET DISTANCE: 30 KM

1	2	3	←
4	5	6	←
7	8	9	✓
↶	0	↷	✓



SET YOUR WORKOUT VALUE

TARGET CALORIES: 30 KCAL

1	2	3	←
4	5	6	←
7	8	9	✓
↶	0	↷	✓

A summary of the exercises will be displayed at the end of the program.



WARM UP

3 min warm-up before training.



Intensity interval



Constant



Ramp



Strengthening



Valley



Mountain



Hills



Fat burning



Cardio



Climb

There are 10 pre-set programs to choose from with different resistances.

Step 1: Select a program.

Step 2: Set the training time.

Step 3: Confirm the program.

Step 4: After completing the program, a summary of the exercises will be displayed.





CONSTANT SPEED

The program automatically adjusts the resistance to reach the set speed value.

Step 1: Choose a program

Step 2: Set speed target.

Step 3: Confirm.

Step 4: After completing the exercise, the exercise summary will be displayed.

SET YOUR WORKOUT VALUE

WORKOUT DURATION : 30 MIN

TARGET SPEED : 30 RPM

1 2 3 ←

4 5 6

7 8 9

↩ 0 ✓

CONSTANT SPEED

DURATION 01:03

DISTANCE 10.5 KM

CALORIES 123 KCAL

AVG. PULSE 120 BPM

MAX. PULSE 131 BPM

AVG. SPEED 10.0 KM/H

AVG. WATT 87 WATT

TOTAL. KJ 68 KJ

SKIP SAVE



CONSTANT WATT

The program automatically adjusts the load to reach the set performance value.

Step 1: Choose a program

Step 2: Set a watt target.

Step 3: Confirm.

Step 4: After completing the exercise, the exercise summary will be displayed.

SET YOUR WORKOUT VALUE

WORKOUT DURATION : 30 MIN

TARGET WATT : 30 W

1 2 3 ←

4 5 6

7 8 9

↩ 0 ✓

CONSTANT WATT

DURATION 01:03

DISTANCE 10.5 KM

CALORIES 123 KCAL

AVG. PULSE 120 BPM

MAX. PULSE 131 BPM

AVG. SPEED 10.0 KM/H

AVG. WATT 87 WATT

TOTAL. KJ 68 KJ

SKIP SAVE



HRC

You can choose one of the three programs 60% / 80% / Target HR (custom). The program always adjusts the resistance so that it is within the set target value.

The target heart rate is always calculated according to the equation: $(220 - \text{age}) * (0.\% \text{ of set value})$.

The user must wear a chest strap or continuously hold the heart rate sensors on the handles.

Step 1: Choose a program.


Step 2: Set program duration.

Step 3: Set 60% / 80% or your own target heart rate.

Step 4: Confirm.

Step 5: If the chest strap is connected, the heart rate icon and Bluetooth will appear.

Step 6: After completing the exercise, you will see a summary of the exercise.




RECOVERY

The test requires constant heart rate measurement, we recommend wearing a chest belt.

Step 1: Select the Recovery program.

Step 2: Before using it for the first time, we recommend that you read the instructions on the screen, or you can skip the instructions by pressing SKIP.



Phase 1: If the heart rate exceeds HR85% of its value after 3 minutes, the test will be marked as a successful test.


Phase 2: Once the heart rate exceeds the value in the range of 110 ~ HR85%, the program will be extended to 4 minutes.

TEST COMPLETED: The test is completed when HR85% or between 110~HR85% is reached, the program will switch to rest mode for 3 minutes.

Step 3: After completing the whole program, the heart rate will be displayed and the change will be monitored for 60 seconds.

Step 4: Then the result from 1 (worst) to 5 (best) stars will be displayed.

Step 5: The exercise summary will be displayed.



USER MODE X3


Set your own exercise program (up to 3 programs), which is divided into 30 segments.

Step 1: Select USER MODE X3.

Step 2: Select one of the three user programs.


Step 3: From left to right, adjust the intensity of all segments.

Step 4: Press OK to save and run the program.



ACCUMULATED WORKOUT SUMMARY

By pressing the profile picture, an interface with log out and a summary of the exercise (history) will be displayed.



Log out: account logout

History: display of exercise summary

Reset: reset all data



HIIT

The HIIT program includes 4 levels of difficulty: primary, intermediate, advanced and challenge. Each difficulty can be divided into 8, 10, 12 and 14 segments, you can set 30, 60 and 90 seconds of rest between each intensity transition.

Step 1: Select a HIIT program.


Step 2: Select a user or practice as a guest.

Step 3: Choose program values.



Step 4: Press Next to start the program. The HIIT program is divided into segments according to colors: warm-up (yellow), sprint (blue-green), recovery (green), calm down (blue). Press SKIP to move to the next screen.

Step 5: After completing the exercise, the exercise summary will be displayed.



USE

Exercise on the exercise bike is based on very simple movements, but you will surely fall in love with them. Thanks to simplicity of the exercise on the exercise bike in can be done by elderly people. Prior to exercise, it is necessary to adjust the height of the saddle. It is important that you sit comfortably. The bicycle saddle must be set so that you can hold the ergonomically shaped handles when sitting. You should not have fully extended hands. You can damage your muscles.

To ensure a comfortable and comfortable exercise, put your feet on the pedal. Nowadays, all modern pedals are equipped with straps for fastening and stabilizing of the foot. It is important for your foot to be firmly and safely positioned during exercise.

The basis of exercising on a bicycle is that the legs are moving on a specific elliptical path. This movement is very similar to cycling. When doing exercise on a bicycle, you just sit on the saddle with the right height, keep your feet firmly in the pedals, hold the ergonomically shaped handles and exercise.

It is advisable at the beginning to choose a lower load. If you exercise at regular intervals on an exercise bike, you can gradually increase the load. You can increase the load gradually over a week or two weeks. Selecting a high load during the start of training can lead to rapid fatigue and muscle damage.

When exercising, it's important to choose the right load and the right tempo. Try to keep it throughout the exercise. It is not recommended to choose a high pace right from the start. Increase tempo after about a week of regular exercise. The high pace is not equal to the faster burning of calories. Correct calorie burning is reflected in an appropriate and regular exercise. At the beginning of the exercise, the number of burned calories may seem low, but regular and appropriate exercise is the key to achieving the best results.

Exercise on the exercise bike also leads to the formation of muscles. It is mainly used to strengthen the thigh and calf muscles. While exercising on a bicycle, you also move your buttocks.

If you want to exercise right, you should not forget to breathe properly. Proper and regular breathing is recommended in any exercise. It is important to keep regular deep inhales and exhales. Regular and proper breathing during exercises on the exercise bike involves intense exercise of the abdominal muscles. It is advisable to practice 30-35 after consuming food. Failure to do so may result in less calories burned, and in older age even lead to digestive problems.

For best results, you should also consider your diet. It is recommended to start a day of eating sweet food and pastries or muesli with milk. For lunch is recommended to eat a caloric richer meal. Do not forget about the soup. In the evening, light meals are recommended. If you want to improve your health, it's not just a regular exercise but a whole diet.

Bicycle exercise is an effective exercise for all busy people. Exercise on the exercise bike is effective in strengthening muscles, especially thighs, calves and buttocks. Regular exercise can lead to a slimmer figure. Exercise is recommended not only as a winter training for cyclists but also for people who want to burn excess calories. Regular breathing, regular exercise, reasonable tempo, and balanced diet can lead to your desired results.

EXERCISING INSTRUCTIONS

A successful workout begins with warm-up exercises and ends with cool-down (relaxing) exercises. The warm-up exercises should make your body ready for the main workout. The cool-down phase should protect your muscles from injuries and cramps. Do warm-up and cool-down exercises as shown in the chart below.



Touching your toes

Slowly bend your back from hips. Keep your back and arms relaxed while stretching downwards to your toes. Do it as far as you are able and hold the position for 15 seconds. Bend your knees slightly.



Upper thigh

Lean against a wall with one hand. Reach down and behind you. Lift up your right or left foot to your buttock as high as possible. Keep for 30 seconds and repeat twice for each leg.



Hamstring stretched

Sit and outstretch your right leg. Rest the sole of your left foot against the inside of your right thigh. Stretch out your right arm along your right leg as far as you can. Hold for 15 seconds and relax. Repeat all with your left leg and left arm.



Inside upper thigh

Sit on the floor and place your feet together. Knees are pointed outwards. Pull your feet as close as possible to your groin. Press your knees carefully downwards. Keep this position for 30-40 seconds if possible.



Calves and Achilles tendon

Lean against a wall with your left leg in front of the right one and your arms forward. Stretch out your right leg and keep your left foot on the floor. Bend your left leg and lean forwards by moving your right hip in the direction of the wall. Hold for 30-40 seconds. Keep your leg stretched and repeat exercising with other leg.

CORRECT BODY POSTURE

When training, keep your body upright, or you can learn your hand on your forearms. During pedaling, you should not have your legs fully extended. Your knees should be slightly bent when fully pressing down the pedal. Keep your head straight with your spine to minimize the pain of the cervical muscles and upper back muscles. Always exercise fluently and rhythmically.

MAINTENANCE

- When assembling, tighten all screws and adjust the bike to the horizontal position.
- Check the screws after 10 hours of use.
- Wipe the sweat after the exercise. Clean the device with a cloth and gentle cleanser. Do not use solvents or aggressive cleaners on the plastic parts.
- When noise is increased, it is necessary to check that all joints are tightened properly.
- Place the product in a clean, ventilated and dry room.
- Do not expose the device to direct sunlight.

STORAGE

Keep the exercise bike in a clean and dry environment. Make sure the power switch is turned off and the exercise bike is not plugged into the power socket.

IMPORTANT NOTICE

- This exercise bike comes with standard safety regulations and is suitable for commercial use. Any other use is prohibited and may be dangerous to users. We are not responsible for any injury caused by improper and forbidden use of the machine.
- Consult your doctor before starting training on the exercise bike. Your doctor should evaluate whether you are physically fit to use the machine and how much effort you are able to undergo. Incorrect exercise or switching of the body can harm your health.
- Carefully read the following tips and exercises. If you experience pain, nausea, breathing, or other health problems during exercise, immediately stop the exercise. If the pain persists, contact your doctor immediately.
- This exercise bike is not suitable as a professional or medical purpose. It can also not be used for healing purposes.
- The heart rate monitor is not a medical device. It provides only approximate information about your average heart rate, and any suggested pulse rate is not medically binding. Accumulated data may not always be accurate regarding uncontrollable human and environmental factors.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyards.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ

SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR

Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK

inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk

About shipping

